

TERMINAL MIX 8 MIDI MAP



DECK1 (channel 0), DECK2 (channel 1), DECK3 (channel 2), DECK4 (channel 3)

No.	Items	Type	SW Note		VR CC		SHIFT +		LED Note		SHIFT +			
			HEX	HEX	HEX	HEX	HEX	HEX	HEX	HEX	HEX	HEX		
1	VINYL	SW	1	1	-	-	65	41	-	-	-	-	-	-
2	SYNC	SW/LED	2	2	-	-	66	42	-	-	2	2	66	42
3	STUTTER	SW/LED	3	3	-	-	67	43	-	-	3	3	67	43
4	CUE	SW/LED	4	4	-	-	68	44	-	-	4	4	68	44
5	PLAY/PAUSE	SW/LED	5	5	-	-	69	45	-	-	5	5	69	45
6	JOG WHEEL(OFF)	SW/ENC	6	6	6	6	70	46	70	46	-	-	-	-
7	JOG WHEEL(ON)	SW/ENC	7	7	7	7	71	47	71	47	-	-	-	-
8	JOG WHEEL(HOLD)	SW/ENC	8	8	8	8	72	48	72	48	-	-	-	-
9	GAIN	VR	-	-	9	9	-	-	73	49	-	-	-	-
10	HIGH(minimum)	SW/VR	10	A	10	A	74	4A	74	4A	-	-	-	-
11	MID(minimum)	SW/VR	11	B	11	B	75	4B	75	4B	-	-	-	-
12	LOW(minimum)	SW/VR	12	C	12	C	76	4C	76	4C	-	-	-	-
13	FILTER(middle)	SW/VR	13	D	13	D	77	4D	77	4D	-	-	-	-
14	CH CUE	SW/LED	14	E	-	-	78	4E	-	-	14	E	78	4E
15	CH FADER	VR	-	-	15	F	-	-	79	4F	-	-	-	-
16	LOAD	SW/LED	16	10	-	-	80	50	-	-	16	10	80	50
17	HOT CUE(MODE1)	SW	17	11	-	-	81	51	-	-	-	-	-	-
18	LOOP(MODE2)	SW	18	12	-	-	82	52	-	-	-	-	-	-
19	SAMPLER(MODE3)	SW	19	13	-	-	83	53	-	-	-	-	-	-
20	SLICE(MODE4)	SW	20	14	-	-	84	54	-	-	-	-	-	-
21	CUE+LOOP	SW	21	15	-	-	-	-	-	-	-	-	-	-
22	CUE+SAMPLER	SW	22	16	-	-	-	-	-	-	-	-	-	-
23	LOOP+SAMPLER	SW	23	17	-	-	-	-	-	-	-	-	-	-
24	DECK FX ASSIGN1	SW/LED	24	18	-	-	88	58	-	-	24	18	88	58
25	DECK FX ASSIGN2	SW/LED	25	19	-	-	89	59	-	-	25	19	89	59
26	SHIFT	SW	31	1F	-	-	-	-	-	-	-	-	-	-
27	DECK	SW	32	20	-	-	-	-	-	-	-	-	-	-
28	CF A	SW	33	21	-	-	-	-	-	-	-	-	-	-
29	CF THRU	SW	34	22	-	-	-	-	-	-	-	-	-	-
30	CF B	SW	35	23	-	-	-	-	-	-	-	-	-	-
31	FADER START CUE	SW	4	4	-	-	-	-	-	-	-	-	-	-
32	FADER START PLAY	SW	5	5	-	-	-	-	-	-	-	-	-	-
33	LOAD Sequence	LED	-	-	-	-	-	-	-	-	48	30	-	-
34	Drum Pad Sequence	LED	-	-	-	-	-	-	-	-	49	31	-	-

FX1 (channel 0) / FX2 (channel 1) / Global (channel 0)

No.	Items	Type	SW Note		VR CC		SHIFT +		LED Note		SHIFT +			
			HEX	HEX	HEX	HEX	HEX	HEX	HEX	HEX	HEX	HEX		
34	FX2_ON(FX_SEL2)	SW/VR/LED	27	1B	27	1B	91	5B	91	5B	27	1B	91	5B
35	FX3_ON(FX_SEL3)	SW/VR/LED	28	1C	28	1C	92	5C	92	5C	28	1C	92	5C
36	BEATS	SW/ENC	29	1D	29	1D	93	5D	93	5D	-	-	-	-
37	TAP	SW/LED	30	1E	-	-	94	5E	-	-	30	1E	94	5E
38	AREA	SW/LED	36	24	-	-	-	-	-	-	36	24	-	-
39	VIEW	SW/LED	37	25	-	-	-	-	-	-	37	25	-	-
40	BACK	SW/LED	38	26	-	-	-	-	-	-	38	26	-	-
41	PREP	SW/LED	39	27	-	-	-	-	-	-	39	27	-	-
42	TRAX	SW/ENC	40	28	40	28	-	-	-	-	-	-	-	-
43	CUE MIX	VR	-	-	41	29	-	-	-	-	-	-	-	-
44	SAMPLER VOL	VR	-	-	42	2A	-	-	-	-	-	-	-	-
45	CROSS FADER	VR	-	-	43	2B	-	-	-	-	-	-	-	-
46	CF CURVE	VR	-	-	44	2C	-	-	-	-	-	-	-	-
47	PITCH BEND(middle)	VR	45	2D	-	-	-	-	-	-	En,0xll(LSB),0xmm(MSB)			
48	VU-Metering	LED(CC)	-	-	-	-	-	-	-	-	1	1	-	-

TERMINAL MIX 8 MIDI MAP



Deck1 Pad (channel 4), Deck2 Pad (channel 5),
Deck3 Pad (channel 6), Deck4 Pad(channel 7)

No.	Items	Type	SW Note		VR CC		SHIFT + SW Note		SHIFT + VR CC		LED Note		SHIFT + LED Note	
				HEX		HEX		HEX		HEX		HEX		HEX
1	HOT_CUE_PAD1	SW/LED	0	0	-	-	64	40	-	-	0	0	64	40
2	HOT_CUE_PAD2	SW/LED	1	1	-	-	65	41	-	-	1	1	65	41
3	HOT_CUE_PAD3	SW/LED	2	2	-	-	66	42	-	-	2	2	66	42
4	HOT_CUE_PAD4	SW/LED	3	3	-	-	67	43	-	-	3	3	67	43
5	HOT_CUE_PAD5	SW/LED	4	4	-	-	68	44	-	-	4	4	68	44
6	HOT_CUE_PAD6	SW/LED	5	5	-	-	69	45	-	-	5	5	69	45
7	HOT_CUE_PAD7	SW/LED	6	6	-	-	70	46	-	-	6	6	70	46
8	HOT_CUE_PAD8	SW/LED	7	7	-	-	71	47	-	-	7	7	71	47
9	LOOP_PAD1	SW/LED	8	8	-	-	72	48	-	-	8	8	72	48
10	LOOP_PAD2	SW/LED	9	9	-	-	73	49	-	-	9	9	73	49
11	LOOP_PAD3	SW/LED	10	A	-	-	74	4A	-	-	10	A	74	4A
12	LOOP_PAD4	SW/LED	11	B	-	-	75	4B	-	-	11	B	75	4B
13	LOOP_PAD5	SW/LED	12	C	-	-	76	4C	-	-	12	C	76	4C
14	LOOP_PAD6	SW/LED	13	D	-	-	77	4D	-	-	13	D	77	4D
15	LOOP_PAD7	SW/LED	14	E	-	-	78	4E	-	-	14	E	78	4E
16	LOOP_PAD8	SW/LED	15	F	-	-	79	4F	-	-	15	F	79	4F
17	SAMPLER_PAD1	SW/LED	16	10	16	10	80	50	80	50	16	10	80	50
18	SAMPLER_PAD2	SW/LED	17	11	17	11	81	51	81	51	17	11	81	51
19	SAMPLER_PAD3	SW/LED	18	12	18	12	82	52	82	52	18	12	82	52
20	SAMPLER_PAD4	SW/LED	19	13	19	13	83	53	83	53	19	13	83	53
21	SAMPLER_PAD5	SW/LED	20	14	20	14	84	54	84	54	20	14	84	54
22	SAMPLER_PAD6	SW/LED	21	15	21	15	85	55	85	55	21	15	85	55
23	SAMPLER_PAD7	SW/LED	22	16	22	16	86	56	86	56	22	16	86	56
24	SAMPLER_PAD8	SW/LED	23	17	23	17	87	57	87	57	23	17	87	57
25	SLICE_PAD1	SW/LED	24	18	-	-	88	58	-	-	24	18	88	58
26	SLICE_PAD2	SW/LED	25	19	-	-	89	59	-	-	25	19	89	59
27	SLICE_PAD3	SW/LED	26	1A	-	-	90	5A	-	-	26	1A	90	5A
28	SLICE_PAD4	SW/LED	27	1B	-	-	91	5B	-	-	27	1B	91	5B
29	SLICE_PAD5	SW/LED	28	1C	-	-	92	5C	-	-	28	1C	92	5C
30	SLICE_PAD6	SW/LED	29	1D	-	-	93	5D	-	-	29	1D	93	5D
31	SLICE_PAD7	SW/LED	30	1E	-	-	94	5E	-	-	30	1E	94	5E
32	SLICE_PAD8	SW/LED	31	1F	-	-	95	5F	-	-	31	1F	95	5F
33	MODE1_PAD1	SW/LED	32	20	-	-	96	60	-	-	32	20	96	60
34	MODE1_PAD2	SW/LED	33	21	-	-	97	61	-	-	33	21	97	61
35	MODE1_PAD3	SW/LED	34	22	-	-	98	62	-	-	34	22	98	62
36	MODE1_PAD4	SW/LED	35	23	-	-	99	63	-	-	35	23	99	63
37	MODE1_PAD5	SW/LED	36	24	-	-	100	64	-	-	36	24	100	64
38	MODE1_PAD6	SW/LED	37	25	-	-	101	65	-	-	37	25	101	65
39	MODE1_PAD7	SW/LED	38	26	-	-	102	66	-	-	38	26	102	66
40	MODE1_PAD8	SW/LED	39	27	-	-	103	67	-	-	39	27	103	67
41	MODE2_PAD1	SW/LED	40	28	-	-	104	68	-	-	40	28	104	68
42	MODE2_PAD2	SW/LED	41	29	-	-	105	69	-	-	41	29	105	69
43	MODE2_PAD3	SW/LED	42	2A	-	-	106	6A	-	-	42	2A	106	6A
44	MODE2_PAD4	SW/LED	43	2B	-	-	107	6B	-	-	43	2B	107	6B
45	MODE2_PAD5	SW/LED	44	2C	-	-	108	6C	-	-	44	2C	108	6C
46	MODE2_PAD6	SW/LED	45	2D	-	-	109	6D	-	-	45	2D	109	6D
47	MODE2_PAD7	SW/LED	46	2E	-	-	110	6E	-	-	46	2E	110	6E
48	MODE2_PAD8	SW/LED	47	2F	-	-	111	6F	-	-	47	2F	111	6F
49	MODE3_PAD1	SW/LED	48	30	-	-	112	70	-	-	48	30	112	70
50	MODE3_PAD2	SW/LED	49	31	-	-	113	71	-	-	49	31	113	71

TERMINAL MIX 8 MIDI MAP



No.	Items	Type	SW Note		VR CC		SHIFT + SW Note		SHIFT + VR CC		LED Note		SHIFT + LED Note	
			HEX	HEX	HEX	HEX	HEX	HEX	HEX	HEX	HEX	HEX	HEX	HEX
51	MODE3_PAD3	SW/LED	50	32	-	-	114	72	-	-	50	32	114	72
52	MODE3_PAD4	SW/LED	51	33	-	-	115	73	-	-	51	33	115	73
53	MODE3_PAD5	SW/LED	52	34	-	-	116	74	-	-	52	34	116	74
54	MODE3_PAD6	SW/LED	53	35	-	-	117	75	-	-	53	35	117	75
55	MODE3_PAD7	SW/LED	54	36	-	-	118	76	-	-	54	36	118	76
56	MODE3_PAD8	SW/LED	55	37	-	-	119	77	-	-	55	37	119	77
57	MODE4_PAD1	SW/LED	56	38	-	-	120	78	-	-	56	38	120	78
58	MODE4_PAD2	SW/LED	57	39	-	-	121	79	-	-	57	39	121	79
59	MODE4_PAD3	SW/LED	58	3A	-	-	122	7A	-	-	58	3A	122	7A
60	MODE4_PAD4	SW/LED	59	3B	-	-	123	7B	-	-	59	3B	123	7B
61	MODE4_PAD5	SW/LED	60	3C	-	-	124	7C	-	-	60	3C	124	7C
62	MODE4_PAD6	SW/LED	61	3D	-	-	125	7D	-	-	61	3D	125	7D
63	MODE4_PAD7	SW/LED	62	3E	-	-	126	7E	-	-	62	3E	126	7E
64	MODE4_PAD8	SW/LED	63	3F	-	-	127	7F	-	-	63	3F	127	7F

Pick up SysEx message 0xf0, 0x7e, 0x7f, 0x56, 0x44, 0x4a, 0x20, 0x69, 0x6e, 0x69, 0x74, 0xf7

RGB COLOUR BEHAVIOUR

Colour	RGB Value	Velocity value
	0,0,0	0x00
	204,0,0	0x01
	204,68,0	0x02
	204,136,0	0x03
	204,204,0	0x04
	136,204,0	0x05
	68,204,0	0x06
	0,204,0	0x07
	0,204,68	0x08
	0,204,136	0x09
	0,204,204	0x0A
	0,136,204	0x0B
	0,68,204	0x0C
	0,0,204	0x0D
	68,0,204	0x0E
	136,0,204	0x0F
	204,0,204	0x10
	204,0,136	0x11
	204,0,68	0x12
	255,255,255	0x13